Westfield Mirror Demister [9087]

Specification & Installation Instructions

Newtech recommends that a registered electrician install this product and that it is installed to the current wiring regulations and in particular to those regulations that include the installation of appliances and accessories in damp environments such as bathrooms. It must be installed in accordance with relevant Australian/New Zealand Standards (AS/NZS).

The Westfield Mirror Demister *[9087]* is designed to leave our range of Westfield mirrors mist free and clear. The mirror demister should be operated for a few minutes before turning on the shower or running a bath.



Sizing Guide

Mirror Size	Demister Size	Demister Required	Watts
400mm	310mm x 450mm	One	2.5W/dm2
500mm	310mm x 450mm	One	2.5W/dm2
600mm	310mm x 450mm	One	2.5W/dm2
750mm	310mm x 450mm	One	2.5W/dm2
900mm	310mm x 450mm	One	2.5W/dm2
1200mm	310mm x 450mm	Two	5W/dm2

Note: The 1200mm Westfield Mirror requires x2 Demisters

INSTALLATION INSTRUCTIONS

1. Lay the Westfield mirror face down on a protective and cushioned surface. Clean the reverse side of the mirror surface making sure it is dry, free of dust and contaminants. Mark the position of the heat pad on the back side of the mirror.

2. Turn the heat pad over. Remove approximately 10cm of the protective film and fold it back.

3. Turn the heat pad again, adjust it to the marked position. Using a dry cloth press the adhesive side to the reverse side of the mirror.

4. Slowly peel the protective film while pressing and rubbing the adhesive side onto the reverse side of the mirror using a dry cloth.

IMPORTANT: Please note a registered electrician is required to complete all wiring installation and connections.

Head Office & Distribution Warehouse
281 Heads Road, Wanganui
Phone: 06 349 0194 or 0800 728 662
sales@newtech.co.nz

Auckland Concept Showroom
525 Great South Road, Penrose, Auckland
Phone: 09 930 6200
aucklandshowroom@newtech.co.nz

newtech.co.nz