
IMPORTANT INSTALLATION NOTICE

Wall Fixing Bracket – Evoke Double Head Slide Shower (ET6112)

Please note: The **lower wall fixing bracket** on the Evoke Double Head Slide Shower (ET6112) must be removed from the rail prior to installation.

See the red box below indicating the lower wall fixing bracket.





IMPORTANT – Loosen or remove the three Grub Screws before removal.

To avoid damage to the slide rail, you must loosen or remove the three grub screws with an Allen key below removing the bracket.

***** Failure to do so may damage the slide rail, and this will void your warranty *****

Instructions:

Step 1:

- Remove the grub screws on both sides of the wall fixing bracket.
- Then remove the gold fixing bracket (this will only detach once both side screws are fully removed).





Step 2:

- Loosen the locking screw (grub screw) inside the wall fixing bracket (only accessible once the gold bracket is removed).
- This locking screw (grub screw) must be fully loosened so the bracket can move freely on the rail without causing damage.





Step 3:

- After the gold bracket is fixed to the wall and the wall bracket is positioned correctly on the rail retighten all three grub screws to secure everything in place.